


DTC 67 V6 PCM



TORQUE CONVERTER CLUTCH "ON-OFF" CIRCUIT FAULT

Circuit Description:

The Torque Converter Clutch (TCC) "ON-OFF" solenoid is a normally open exhaust valve. The PCM activates the solenoid by earthing circuit 422 with an internal quad-driver. When the solenoid is energised it blocks the fluid from exhausting the TCC circuit and the TCC is applied.

The PCM continually monitors voltage on the TCC circuit connected to the "quad driver" for either low or high voltage depending on the commanded state of the torque converter clutch. Diagnostic Trouble Code (DTC) 67 will set if there is a fault detected on the TCC solenoid circuit. For example, if the TCC were "OFF," but voltage on the TCC circuit drops as if the solenoid were applied, then DTC 67 will be set. If the TCC were "ON" but voltage on the TCC circuit remains high (about 12 volts), as if TCC solenoid were not applied, then DTC 67 will be set.

Test Description: Number(s) below refer to step number(s) on the diagnostic chart.

2. Diagnostic Trouble Code 67 will set if:
 - TCC signal circuit 422 is open or shorted to earth for 2 seconds.
 - This test checks to identify if the TCC circuit is currently open or shorted to earth.
3. This test checks for a short to voltage on circuit 422.
4. This test checks for resistance in the TCC solenoid and internal transmission harness.
5. This test checks for power to the Torque Converter Clutch (TCC) solenoid.
6. This test verifies that circuit 422 is not shorted to earth.
7. This test verifies that circuit 422 is not open.

Diagnostic Aids:

Be sure to check all connections especially those at the transmission pass-thru connector.

TCC solenoid resistance should be 20-40 ohms minimum when measured at 20 degrees C. Maximum solenoid current flow should not exceed 1.5 amps.

DTC 67 will only find an electrical fault with the torque converter clutch. DTC 69 will diagnosis mechanical faults with the torque converter clutch. Some slight TCC slip is normal. When diagnostic trouble Code 67 is set, the transmission will have no TCC and no 4th gear, if in the hot mode.

DTC 67 V6 PCM

TORQUE CONVERTER CLUTCH "ON-OFF" CIRCUIT FAULT

STEP	ACTION	VALUE	YES	NO
1.	Was the "On-Board Diagnostic" (OBD) System Check performed?		Go to Step 2	Go to OBD System Check in this Section
2.	1. Ignition "ON". 2. Record then clear DTCs. 3. Ignition "OFF" for 10 seconds. 4. Ignition "ON". 5. Using Tech 1 "Scan" tool, select "F2: TRANSMISSION", then "FO: DATA LIST", then "FO: ALL", then select "TCC FDBK". 6. Does TCC FDBK display "OFF"?		Go to Step 3	Go to Step 4
3.	1. Ignition "ON", engine idling. 2. Make sure ECT is above 51 degrees C. 3. Make sure TFT is above 20 degrees C. 4. Place transmission in drive range "D" and accelerate vehicle to 80 km/h and maintain this speed for 10 seconds. 5. Does the "TCC FDBK" display "ON"?		DTC 67 is intermittent, if no additional DTCs were stored. Refer to "Diagnostic Aids" on facing page.	Short to voltage in circuit 422
4.	1. Ignition "OFF". 2. Raise vehicle. 3. Disconnect transmission Pass-Thru connector. 4. Connect jumper harness J 39775 to transmission only. 5. Using ohmmeter measure resistance across harness terminals "E" and "T" at the free end of jumper harness. 6. Is ohmmeter reading within specified value?	20 to 40 Ohms	Go to Step 5	If more than specified value, Go to Step 10 ----- If less than specified value, Go to Step 13
5.	1. Disconnect jumper harness J 39775 . from transmission, and connect other end into powertrain harness. 2. Ignition "ON". 3. Using DVM check for battery voltage at terminal "E" of the powertrain wiring harness. 4. Is battery voltage present?		Go to Step 6	Go to Step 14

6.	1. Ignition "ON". 2. With test light connected to +12 volts, probe powertrain wiring harness terminal "T". 3. Is test light "OFF"?	Go to Step 7	Go to Step 15
7.	1. Ignition "ON". 2. Reconnect transmission Pass-Thru connector. 3. Backprobe PCM connector terminal for circuit 422 with a test light connected to earth. 4. Is test light "ON"?	Go to Step 8	Go to Step 16
8.	1. Check for poor connection at PCM. 2. Is a poor connection found?	Verify Repair	Go to Step 9
9.	1. Replace PCM. 2. Is action complete?	Verify Repair	
10.	1. Check for faulty connection. 2. Is a faulty connection found?	Verify Repair	Go to Step 11
11.	1. Check for a open in transmission internal wiring harness. 2. Is an open found ?	Verify Repair	Go to Step 12
12.	Replace faulty TCC solenoid. Is action complete ?	Verify Repair	
13.	1. Check transmission internal wiring harness for short to earth. 2. Is a short to earth found ?	Verify Repair	Go to Step 12
14.	Repair faulty transmission fuse F12 or short to earth in circuit 339. Is action complete?	Verify Repair	
15.	1. Check for short to earth on circuit 422. 2. Is circuit 422 shorted to earth?	Verify Repair	Go to Step 9
16.	1. Check for poor connection at transmission pass-thru connector. 2. Is fault found?	Verify Repair	Go to Step 17
17.	Repair open in circuit 422.		