


5J	MODELS EXECUTIVE & BERLINA WITH V6 L.P.G	VX
L.P.G CONTROL MODULE		



NOTE:- CONVENTIONAL CURRENT FLOW IS ASSUMED IE.
FLOWING FROM BATTERY +VE TO BATTERY -VE.

NOTE :- YR51 WAGON TANK CONNECTOR
YR50 SEDAN TANK CONNECTOR

WIRING DIAGRAMS

HARNESS SYMBOLS: (M.V.M.H.) (BAT.) (P.T.) (B.) (L.P.G.)

