



NOTE:- CONVENTIONAL CURRENT FLOW IS ASSUMED IE.  
FLOWING FROM BATTERY +VE TO BATTERY -VE

WIRING DIAGRAMS

HARNESS SYMBOLS: (M.W.H.) (BAT.) (E.) (P.T.) (B.)

