



A5 POWERTRAIN INTERFACE MODULE




P.T.H.

A111 THROTTLE ACTUATOR CONTROL MODULE




P.T.H.

X206 F.B.H. TO P.T.H.




F.B.H.

P.T.H. TO F.B.H.




P.T.H.

V04_12PA005




LHD MANUAL A/C SHOWN




A

M3-LHD



LHD O.C.C. (AUTO A/C) SHOWN




B

M3-LHD


A13-LHD

A13-LHD BLOWER & AIR INLET




F.B.H.

M3-LHD BLOWER MOTOR




B.M.H.

R6-LHD BLOWER MOTOR RESISTOR




F.B.H.

V04_12PA013-LHD




RHD MANUAL A/C SHOWN




M3-RHD

A




RHD O.C.C. (AUTO A/C) SHOWN



M3-RHD


B

A13-RHD BLOWER & AIR INLET




F.B.H.

M3-RHD BLOWER MOTOR




F.B.H.

R6-RHD BLOWER MOTOR RESISTOR




F.B.H.

V04_12PA013-RHD




A14-X1 BLOWER MOTOR & A/C COMPRESSOR




F.B.H.


A14-X2 BLOWER MOTOR & A/C COMPRESSOR




O.C.C.H.




V04_12PA014









LEVEL 3 RHD SHOWN
CV8 DRIVERS SEAT SIMILAR




EARLY PRODUCTION



LATE PRODUCTION






C




D

A21-X1 DRIVERS SEAT ADJUSTER MEMORY PS.H. EARLY PRODUCTION	A21-X2 DRIVERS SEAT ADJUSTER MEMORY PS.H. EARLY PRODUCTION	A21-X3 DRIVERS SEAT ADJUSTER MEMORY PS.H. EARLY PRODUCTION	A21-X4 DRIVERS SEAT ADJUSTER MEMORY PS.H. EARLY PRODUCTION
A21-X1 DRIVERS SEAT ADJUSTER MEMORY PS.H. LATE PRODUCTION	A21-X2 DRIVERS SEAT ADJUSTER MEMORY PS.H. LATE PRODUCTION	A21-X3 DRIVERS SEAT ADJUSTER MEMORY PS.H. LATE PRODUCTION	A21-X4 DRIVERS SEAT ADJUSTER MEMORY PS.H. LATE PRODUCTION






P6 DRIVER INFORMATION




G.P.S.H.


A35 DRIVER INFO DISPLAY CONTROL








A35 DRIVER INFO DISPLAY CONTROL



V04_12PA035




SEDAN SHOWN, WAGON,
UTILITY & COUPE SIMILAR



A158-X1


COMMUNICATION
CENTRE CALL



F.B.H.

A158-X2


COMMUNICATION
CENTRE CALL



F.B.H.

A158-X3


COMMUNICATION
CENTRE CALL



F.B.H.

A158-X4


COMMUNICATION
CENTRE CALL



F.B.H.

A158-X5


COMMUNICATION
CENTRE CALL



TELEMATIC MODULE


E124


INSIDE REAR VIEW MIRROR





B.W.H.

V04_12PA158









SEDAN WITH S/C







SEDAN EXCEPT S/C




UTILITY






A55 FUEL SENDER & PUMP CONTROL MODULE	A55 FUEL SENDER & PUMP CONTROL MODULE	A55 FUEL SENDER & PUMP CONTROL MODULE
 <p>L.P.G.H. SEDAN</p>	 <p>L.P.G.H. WAGON</p>	 <p>L.P.G.H. UTILITY</p>



RHD SHOWN
LHD SIMILAR

A60-X1


HEATER & A/C
EVAPORATOR MODULE




F.B.H.

A60-X2

HEATER & A/C
EVAPORATOR MODULE




F.B.H.




A60-X2

A60-X1

V04_12PA060



A62 INSTRUMENT PANEL INFLATOR
RESTRAINT MODULE




P.A.B.H.


X205

F.B.H. TO P.A.B.H.

P.A.B.H. TO F.B.H.





F.B.H.




P.A.B.H.

V04_12PA062




A65 INFLATION RESTRAINT SENSOR





B.W.H.

A65 FRSIR INFLATION RESTRAINT SENSOR




B.W.H.

V04_12PA065




A
SEDAN RH SIDE SHOWN
WAGON & COUPE SIMILAR

A66 INFLATION RESTRAINT
SIDE IMPACT SENSOR




B.W.H.

X300 B.W.H. TO R.L.H




B.W.H.

R.L.H. TO B.W.H



R.L.H.


V04_12PA066




A73-X2 OUTSIDE REAR VIEW
MIRROR MEMORY MODULE




O.S.R.M.H. LEVEL 3 ONLY



V04_12PA073




A83 PARK/NEUTRAL POSITION SWITCH




P.T.H.

S187 PRNDL SWITCH




P.T.H.



X121-X2 TRANSMISSION ASSEMBLY






P.T.H.




V04_12PA083




A84-V6-X1 A84-V6SC-X1	POWERTRAIN CONTROL MODULE	A84-V6-X2 A84-V6SC-X2	POWERTRAIN CONTROL MODULE	A84-V6-X3 A84-V6SC-X3	POWERTRAIN CONTROL MODULE
--	------------------------------	--	------------------------------	--	------------------------------





A84-V8-X1	POWERTRAIN CONTROL MODULE
------------------	---------------------------



A84-V8-X2	POWERTRAIN CONTROL MODULE
------------------	---------------------------









RIGHT SEAT SHOWN

A96


FRONT SIDE RAIL
INFLATOR RESTRAINT




S.A.B.H.




V04_12PA096




SEDAN



COUPE




A



B

A98


REAR OBJECT
SENSOR CONTROL



B.W.H.


H31

REAR OBJECT SENSOR
ALARM




B.W.H.


V04_12PA098



A106 STEERING WHEEL INFLATOR RESTRAINT MODULE




CLOCK SPRING



LEVEL 3 SHOWN

A121 WINDSHIELD WIPER DWELL MODULE




F.B.H.

S7 STEERING WHEEL HORN



CLOCK SPRING

S43 CRUISE CONTROL SWITCH




F.B.H.

S208-X1 RADIO CONTROL SWITCH




CLOCK SPRING

S208-X2 RADIO CONTROL SWITCH




CLOCK SPRING LEVEL 3 ONLY

S231 TURN SIGNAL & HEADLAMP SWITCH




F.B.H.

S247 WINDSHIELD WIPER & WASHER SWITCH




F.B.H.

X116 STEERING WHEEL CLOCK SPRING COIL





F.B.H.


V04_12PA106




R.H.D. SEDAN SHOWN
L.H.D. SIMILAR



A108-X1 SUN ROOF CONTROL **A108-X2** SUNROOF CONTROL




S.R.P.H.




B

A108-X3 SUNROOF CONTROL




S.R.H

S228 SUNROOF




S.R.C.H

X321 S.R.H. TO S.R.C.H




S.R.H


S.R.C.H. TO S.R.H.



S.R.C.H V04_12PA108




RHD SHOWN



A133-X1


RADIO, CLOCK & CD
PLAYER



F.B.H.

A133-X2


POWER ANTENNA



F.B.H.


A133-X3

DIVERSITY ANTENNA




F.B.H.

V04_12PA133



COUPE DRIVERS SEAT SHOWN




A138-X1

A

ALL COUPE SEATS EXCEPT
CV8 DRIVERS SEAT

A138-X2


S57



B


ALL COUPE SEATS

A138-X1 FRONT SEAT ADJUSTER
MEMORY MODULE




P.S.H.

A138-X2 FRONT SEAT ADJUSTER
MEMORY MODULE











P.S.H.


S57 EZ ENTRY SWITCH




R.S.H.



V04_12PA138









RIGHT SEAT SHOWN





R.S.H.

V04_12PS267






B23 AMBIENT AIR TEMPERATURE
SENSOR




LEVELS 2 & 3


F.B.H.

V04_12PB023






"V6" SHOWN
"V6 S/C" SIMILAR




B28-V6 CAMSHAFT POSITION
SENSOR




P.T.H.

B30-V6 CRANKSHAFT POSITION
SENSOR










P.T.H.

V04_12PB028-V6








"GEN III V8" AUTOMATIC
SHOWN




B28-V8 CAMSHAFT POSITION SENSOR	B30-V8 CRANKSHAFT POSITION SENSOR	B42 ENGINE OIL PRESSURE SENSOR	B67 M.A.P. SENSOR
 <p>P.T.H.</p>	 <p>P.T.H.</p>	 <p>P.T.H.</p>	 <p>P.T.H.</p>


V04_12PB028-V8



B34-RHD DUCT AIR TEMPERATURE SENSOR	B34-LHD DUCT AIR TEMPERATURE SENSOR	Y37-RHD ACTUATOR TEMPERATURE VALVE (AIR MIX MOTOR)	Y37-LHD ACTUATOR TEMPERATURE VALVE (AIR MIX MOTOR)
			
O.C.C.H.	O.C.C.H.	O.C.C.H.	O.C.C.H.




"V6" ENGINE SHOWN
"V6 S/C" SIMILAR



A


"V6 & V6 S/C"



B


"GEN III V8"

B39 ENGINE COOLANT
TEMPERATURE SENSOR




B


A



B

"GEN III V8" ENGINE






B56-L-V6SC

HEATED OXYGEN
SENSOR

B57-R-V6SC


HEATED OXYGEN
SENSOR (POSITION 2)




P.T.H.





P.T.H.



V04_12PB056-V6SC








B65 "V6" & "V6 S/C"
(R. SIDE SHOWN)


B65


KNOCK SENSOR




P.T.H.


V04_12PB065









SEDAN SHOWN




SEDAN, WAGON & COUPE SHOWN




UTILITY SHOWN

B76 REAR WHEEL SPEED SENSOR




B.W.H.


V04_12PB076




"V6" ENGINE SHOWN
"V6 S/C" SIMILAR




A
"V6"



B
"V6 S/C"




"GEN III V8" ENGINE




C
"GEN III V8"

B82 THROTTLE POSITION
SENSOR




P.T.H.

Y20 IDLE SPEED CONTROL
ACTUATOR




P.T.H.




SEDAN, WAGON AND UTILITY R.H. FRONT DOOR SHOWN
COUPE SIMILAR


B108 RADIO RH & LH DOOR
SPEAKER




D.W.H.

V04_12PB108






SEDAN AND WAGON R.H. REAR DOOR SHOWN



COUPE LEFT SIDE SHOWN

B117 RADIO RH & LH DOOR
SPEAKER




D.W.H.


V04_12PB117

B131


**REAR SPEAKER RADIO
AMPLIFIER**




B.W.H.




SEDAN R. SIDE SHOWN
COUPE SIMILAR





V04_12PB131




SEDAN SHOWN
COUPE SIMILAR











A
L. SIDE



D
4 PLACES




C
R. SIDE


<p>B133 REAR OBJECT SENSOR</p>  <p>R.P.A.H.</p>	<p>X156 INLINE TO REAR OBJECT SENSOR HARNESS</p>  <p>B.W.H.</p>	<p>X905 B.W.H. TO R.P.A.H.</p>  <p>B.W.H.</p>	<p>R.P.A.H. TO B.W.H.</p>  <p>R.P.A.H.</p>
<p>X906 B.W.H. TO B.W.H. TOW HOOK A</p>  <p>B.W.H.</p>	<p>B.W.H. TO B.W.H. TOW HOOK B</p>  <p>B.W.H.</p>	<p>X907 B.W.H. TO B.W.H. TRAILER A</p>  <p>B.W.H.</p>	<p>B.W.H. TO B.W.H. TRAILER B</p>  <p>B.W.H.</p>




RIGHT SEAT SHOWN




A
LEVEL 3 SEAT SHOWN
EARLY PRODUCTION




B
LEVEL 3 SEAT SHOWN
LATE PRODUCTION




D
LEVEL 1 RHD, LEVELS 1 & 2 LHD
& ALL COUPE EXCEPT CV8 DRIVERS



C
LEVEL 2 RHD SHOWN, LEVEL 3
& CV8 DRIVERS SEAT SIMILAR




E
LEVELS 1, 2 &
ALL COUPE EXCEPT CV8 DRIVERS




F
LEVEL 3 & CV8 DRIVERS SEAT

**Y67-D
Y84-P** SEAT INNER ADJUSTER
FRT VERT ACTUATOR




L3, CV8 DRIVERS & RHD L2
P.S.H. EARLY PRODUCTION

**Y67-D
Y84-P** DRIVERS SEAT INNER
ADJUSTER FRT VERT
ACTUATOR




ALL L1, LHD L2, ALL CV6 &
CV8 PASSENGER
P.S.H. EARLY PRODUCTION

**Y67-D
Y84-P** DRIVERS SEAT INNER
ADJUSTER FRT VERT
ACTUATOR




P.S.H. LATE PRODUCTION

**Y69-D
Y86-P** DRIVERS SEAT INNER
ADJUSTER REAR VERT
ACTUATOR




L3, CV8 DRIVERS & RHD L2
P.S.H. EARLY PRODUCTION

**Y69-D
Y86-P** DRIVERS SEAT INNER
ADJUSTER REAR VERT
ACTUATOR



ALL L1, LHD L2, ALL CV6 &
CV8 PASSENGER
P.S.H. EARLY PRODUCTION


**Y69-D
Y86-P** DRIVERS SEAT INNER
ADJUSTER FRT VERT
ACTUATOR




P.S.H. LATE PRODUCTION




RIGHT SEAT SHOWN




LEVEL 2 SEAT SHOWN
EARLY PRODUCTION



LEVEL 2 SEAT SHOWN
LATE PRODUCTION




B
EARLY PRODUCTION




B
LATE PRODUCTION

B138 DRIVER SEAT HORIZONTAL
POSITION SENSOR




PS.H. EARLY PRODUCTION

B142 PASSENGER SEAT HORIZONTAL
ADJUSTER POSITION SENSOR




PS.H. EARLY PRODUCTION

**Y64-D
Y81-P** SEAT ADJUSTER
HORIZONTAL ACTUATOR




PS.H. EARLY PRODUCTION

**Y64-D
Y81-P** SEAT ADJUSTER
HORIZONTAL ACTUATOR




RHD L2
PS.H. EARLY PRODUCTION

**Y64-D
Y81-P** SEAT ADJUSTER
HORIZONTAL ACTUATOR




PS.H. LATE PRODUCTION



RIGHT SEAT SHOWN


Y74
Y91



A

LEVEL 2 RHD, LEVEL 3,
& ALL COUPE SEATS
EARLY PRODUCTION


Y74
Y91



B


LEVEL 2 RHD
& ALL COUPE SEATS
EXCEPT CV8 DRIVER
LATE PRODUCTION

Y74
Y91



C

LEVEL 3 & CV8 DRIVERS SEAT ONLY
LATE PRODUCTION




D

B139
(LEVEL 3 & CV8)

LEVEL 3 & CV8 DRIVERS SEAT ONLY
EARLY PRODUCTION

B139


DRIVER SEAT RECLINE
POSITION



R.S.H. EARLY PRODUCTION

Y74-D
Y91-P


SEAT RECLINE
ACTUATOR





P.S.H. EARLY PRODUCTION

Y74-D
Y91-P

DRIVERS SEAT RECLINE
ACTUATOR



P.S.H. LATE PRODUCTION




A

LEVELS 1 & 2 RHD
RIGHT SIDE ONLY



LEVELS 2 & 3 R.H.D.
SHOWN



C

B9-X1

HORN




F.B.H.

B9-X2

HORN




F.B.H.






B

RIGHT SIDE SHOWN
(WHERE FITTED)

V04_12PB009






A

R.H.D. SHOWN

E30


IGNITION LOCK
CYLINDER BULB



F.B.H.

S149-X1


IGNITION & START
SWITCH



F.B.H.

S149-X2

IGNITION & START
SWITCH



F.B.H.



S149-GP15-X3

IGNITION & START
SWITCH





F.B.H.

V04_12PE030




A
SEDAN SHOWN
COUPE SIMILAR



B
STATION WAGON


E36 - X1 REAR COMPARTMENT
COURTESY LAMP



A


E.G.H.
B.W.H.

E36 - X2 REAR COMPARTMENT
COURTESY LAMP




A

E.G.H.
B.W.H.



E44-S/C

REAR LICENCE
PLATE LAMP



B.W.H. SEDAN & COUPE

E44-W

REAR LICENCE
PLATE LAMP



E.G.H. WAGON



E44-U

REAR LICENCE
PLATE LAMP





R.B.W.H.

V04_12PE044




SEDAN R. SIDE
LEVELS 1 & 2 SHOWN
LEVEL 3 SIMILAR



COUPE R. SIDE SHOWN

E48-S/C


STOP/TAIL LAMP



T.L.H.

E56-S/C


STOP/TAIL LAMP



T.L.H.



E101-S/C

STOP/TAIL LAMP





T.L.H.

V04_12PE048-S/C






WAGON R. SIDE SHOWN





R. SIDE SHOWN

E48-W/U	STOP/TAIL LAMP	E56-W/U	BACK-UP LAMP	E101-W/U	REAR TURN SIGNAL LAMP
T.L.H.	A B	T.L.H.	A B	T.L.H.	A B C




E67-X1-L1	DOME LAMP	E67-X1-L2/L3	DOME LAMP
<p>1 4</p>		<p>1 6</p>	
R.L.H.	L1	V.L.H.	L2 & L3






SEDAN R. SIDE SHOWN



A



B

E72-X1
E72-X2

FRONT SIDE DOOR
COURTESY LAMP




L.H.F.D.W.H.
R.H.F.D.W.H.

(D.W.H)


E99-X1
E99-X2


REAR SIDE DOOR
COURTESY LAMP




L.H.R.D.W.H.
R.H.R.D.W.H.

(D.W.H)







LEVEL 1 L.H. SHOWN



LEVEL 1 R.H. SHOWN




LEVEL 2 & 3 L.H. SHOWN
COUPE SIMILAR



LEVEL 2 & 3 R.H. SHOWN
COUPE SIMILAR

E76


TURN SIGNAL LAMP




F.B.H.

E83

HEADLAMP





F.B.H.





A

SEDAN WITH SPOILER




B

SS UTILITY SHOWN




C

COUPE



E79-C

HIGH MOUNTED
STOP LAMP




B.W.H.

COUPE

E79-U

HIGH MOUNTED
STOP LAMP




R.L.H.

SS UTE

E80



HIGH MOUNTED
STOP LAMP



B.W.H.



SS SEDAN

V04_12PE079_C



A

SEDAN WITHOUT SPOILER




B

WAGON



E79-S/W

HIGH MOUNTED
STOP LAMP




B.W.H. SEDAN & WAGON

V04_12PE079_SW



E82-X1
E82-X2


INSTRUMENT PANEL
LAMP



F.B.H.

S142-X1
S142-X2

INSTRUMENT PANEL
LAMP SWITCH




F.B.H.


A

RHD SHOWN
LHD SIMILAR

V04_12PE082




SEDAN SHOWN
WAGON SIMILAR



E94-X1


READING LAMP



R.L.H.

E94-X2


READING LAMP



R.L.H.

E94-X3

READING LAMP





R.L.H.





ALL LEVELS


V04_12PE094













G1-X1 BATTERY POSITIVE		G1-GP1-X2 BATTERY NEGATIVE	
BATT.W.H.		BATT.W.H.	
X86-A	FUSIBLE LINK SUPPLY	X86-B	START & GENERATOR
BATT.W.H.		BATT.W.H.	
X86-C	DC-SENSE	X86-D	BATTERY WIRING HARNESS GROUND
BATT.W.H.		BATT.W.H.	




"V6" ENGINE SHOWN
"V6 S/C" SIMILAR




C


"V6 & V6 S/C"




"GEN III V8" ENGINE




A
"V6"



B
"V6 S/C"




D
"GEN III V8"



E
"GEN III V8"


G8-X1 GENERATOR



A

BATT.W.H.

G8-X2 GENERATOR




A

B

BATT.W.H.

M15-X1 STARTER MOTOR



A

BATT.W.H.



M15-X2 STARTER MOTOR




A

BATT.W.H.

V04_12PG008






L2 FUEL INJECTOR



P.T.H.


V04_12PL002






A

V6 STANDARD FANS SHOWN
V6 H.P. FANS SIMILAR




B


"GEN III V8"



D



E




M7-X1

ENGINE COOLING FAN

ENGINE COOLING FAN

ENG COOL FAN ASM.

F.B.H.



M7-X2-V6


ENGINE COOLING FAN

ENGINE COOLING FAN

ENG COOL FAN ASM.

V6 STANDARD FANS

ENG COOL FAN ASM.



M7-X2-V6HP-V8

ENGINE COOLING FAN


ENGINE COOLING FAN

ENG COOL FAN ASM



V6 H.P. & "GEN III V8" FANS

ENG COOL FAN ASM


V04_12PM007



SEDAN SHOWN WAGON &
COUPE SIMILAR




UTILITY




B

M8 FUEL PUMP MOTOR




F.T.H.

X402 B.W.H. TO F.T.H.




B.W.H.

F.T.H. TO B.W.H.




F.T.H.


V04_12PM008




SEDAN R.SIDE SHOWN



B
SEDAN & WAGON
EARLY PRODUCTION




A
SEDAN, WAGON & UTILITY
SHOWN, COUPE SIMILAR




B
SEDAN & WAGON
LATE PRODUCTION

M10 FRONT SIDE DOOR
WINDOW REGULATOR




D.W.H.

M14 REAR SIDE DOOR
WINDOW REGULATOR





D.W.H. EARLY PRODUCTION

M14 REAR SIDE DOOR
WINDOW REGULATOR




D.W.H. LATE PRODUCTION



V04_12PM010





D.W.H.





P.M.H. LEVEL 3 ONLY
X502 P.M.H TO L.H.F.D.W.H.




P.M.H. LEVEL 3 ONLY
L.H.F.D.W.H TO P.M.H.




P.M.H. LEVEL 3 ONLY
X602 P.M.H TO R.H.F.D.W.H.



R.H.F.D.W.H. (RHD) (D.W.H)
R.H.F.D.W.H TO P.M.H.






WAGON

M12 REAR WINDOW WIPER MOTOR

X118-GP14


B.W.H. GROUND
DECK LID





E.G.H.




B.W.H.



V04_12PM012





M17 WINDSHIELD WIPER MOTOR




A

R.H.D. SHOWN
L.H.D. SIMILAR




A
SEDAN AND
UTILITY SHOWN



B

M19

WINDSHIELD WIPER &
WINDSHIELD WASHER



F.B.H.

S135-X1
S135-X2


HOOD THEFT
DETERRENT



F.B.H.

V04_12PM019


N6



N6



RADIO REAR SPEAKER
AMPLIFIER

SEDAN SHOWN
COUPE SIMILAR




B.W.H

V04_12PN006




W4

N3



N3


RADIO ANTENNA
AMPLIFIER



F.B.H.





W4

RADIO DIVERSITY ANTENNA




D.A.A.H.


V04_12PN003




F.B.H.

V04_12PP003





SEDAN SHOWN
COUPE, WAGON AND UTILITY SIMILAR




S2 DOOR AJAR INDICATOR
SWITCH




R.L.H.
B.W.H.

V04_12PS002





"V6" MANUAL SHOWN
"GEN III V8" SIMILAR

S32 BACK UP LAMP SWITCH



P.T.H.

V04_12PS032




A

R.H.D. SHOWN
L.H.D. SIMILAR






S37

**BRAKE PRESSURE
DIFFERENTIAL**




F.B.H.

V04_12PS037




S42 CLUTCH PEDAL POSITION SWITCH




F.B.H.

S46 CRUISE CONTROL RELEASE & CLUTCH PEDAL SWITCH




C.C.P.H.

S220-X1 STOP LAMP, TRACTION & CRUISE CONTROL RELEASE SWITCH




F.B.H.

S220-X2 STOP LAMP, TRACTION & CRUISE CONTROL RELEASE SWITCH




F.B.H.

S220-X3 STOP LAMP, TRACTION & CRUISE CONTROL RELEASE SWITCH




F.B.H.

X316 F.B.H. TO C.C.P.H.




F.B.H.


C.C.P.H. TO F.B.H.




C.C.P.H.

V04_12PS042






RIGHT SEAT SHOWN



**S50-D
S175-P**

A

LEVEL 1 &
LEVEL 2 RHD




**S51-D
S176-P**

**X314-D
X323-P**

B

LEVEL 2 LHD &
LEVEL 3 RHD PASSENGER




S52

X314

S51

C


LEVEL 3 SEAT SHOWN
CV8 DRIVERS SIMILAR



D


ALL COUPE EXCEPT CV8 DRIVERS SEAT

S50 DRIVER SEAT ADJUSTER
SWITCH




P.S.H.

S51 DRIVERS SEAT
ADJUSTER & RECLINE




P.S.H.

S52 DRIVER SEAT ADJUSTER
MEMORY SWITCH




S175 PASSENGER SEAT
ADJUSTER




P.S.H.

S176 PASSENGER SEAT
ADJUSTER & RECLINE



P.S.H.

X314 P.S.H. TO R.S.H.




P.S.H.


LEVEL 3

X314 P.S.H. TO S.B.H.

S.B.H. TO P.S.H.



P.S.H.




CV8


S.B.H.

X323 P.S.H. TO R.S.H.

R.S.H. TO P.S.H.



P.S.H.




2


1

R.S.H.


V04_12PS050




SEDAN R. SIDE SHOWN



B
LEVELS 1, 2 & 3



A



C


SEDAN & WAGON

S63 DOOR LOCK SWITCH




L.H.F.D.H. (LHD)
R.H.F.D.H. (RHD)

Y13 FRONT SIDE DOOR LOCK ACTUATOR




L.H.F.D.W.H. (D.W.H.)
R.H.F.D.W.H. (D.W.H.)

Y31 REAR SIDE DOOR LOCK ACTUATOR




L.H.R.D.W.H. (D.W.H.)
R.H.R.D.W.H. (D.W.H.)




S84

ENGINE COOLANT
LEVEL SWITCH




P.T.H.



A

"GEN III V8" ONLY


V04_12PS084



"V6 & V6 S/C"


S87

ENGINE OIL PRESSURE
INDICATOR SWITCH




P.T.H.


V04_12PS087




S118 FUEL TYPE INDICATOR SWITCH






F.B.H.




V04_12PS118



RHD SHOWN
LHD SIMILAR




S120 HAZARD WARNING




F.B.H.

S125 HEADLAMP AUTOMATIC CONTROL SWITCH





F.B.H.

S237 TRIP ODOMETER RESET SWITCH




F.B.H.

V04_12PS120




B



A

S156


INTERIOR LIGHTS
OVER-RIDE SWITCH



9C1 I.I.H.

X7


FUSE



9C1 I.I.H.


X133

FUSE BLOCK




9C1 I.I.H.


V04_12PS156






SEDAN SHOWN




S181 PARK BRAKE SWITCH






S187 PARK/NEUTRAL POSITION
& BACK/UP LAMP





X121-X2 TRANSMISSION ASSEMBLY





P.T.H.


P.T.H.

V04_12PS187




A
 SEDAN SHOWN
 COUPE & WAGON SIMILAR

<p>S189-X1 REAR COMPARTMENT COURTESY LAMP SWITCH</p>  <p>A</p> <p>E.G.H. B.W.H.</p>	<p>S189-X2 REAR COMPARTMENT THEFT DETERRENT SWITCH</p>  <p>A</p> <p>E.G.H. B.W.H.</p>
---	---




S191

**FUEL FILLER
DOOR RELEASE**






F.B.H.




A



LHD ONLY

V04_12PS191




V04_12PS195










S222 SIDE WINDOW (MASTER) SWITCH





A

RHD SHOWN
LHD SIMILAR











X40 WIRING (DIAGNOSTIC)




F.B.H.




A




R.H.D. SHOWN
L.H.D. OPPOSITE

V04_12PX040









"GEN III V8" SHOWN
"V6" SIMILAR




X86-E	X86-F	X126-AUX	FUSE BLOCK ASSEMBLY
<p>AUXILIARY POSITIVE</p>  <p>9C1 A.P.H.</p>	<p>AUXILIARY NEGATIVE</p>  <p>9C1 A.P.H.</p>	<p>9C1 A.P.H.</p>	

V04_12PX086E







X94


AUXILIARY BATTERY HARNESS JUNCTION




X89-AUX 2
TOTAL APPLIED LOAD
IS LIMITED BY A 50 AMP
FUSIBLE LINK


X89-AUX 1
TOTAL APPLIED LOAD
IS LIMITED BY A 50 AMP
FUSIBLE LINK






X100 ENGINE WIRING HARNESS JUNCTION










"V6 & V6 S/C"



"GEN III V8"









X118-GP8 RADIO GROUND





F.B.H.





RHD SHOWN
LHD OPPOSITE



V04_12PX118_GP08



X118-GP9	BODY GROUND	X119-GP10	INSTRUMENT PANEL GROUND
			
INSTRUMENT PANEL TO BODY GROUND STRAP		BODY TO INSTRUMENT PANEL GROUND STRAP	

V04_12PX118_GP09

X118-GP11 INFLATION RESTRAINT
CONTROL




B.W.H.


X118-GP12 B.W.H. GROUND
TRANSMISSION
TUNNEL




B.W.H.





RHD SHOWN
LHD SIMILAR





V04_12PX118_GP11




SEDAN SHOWN
COUPE SIMILAR



WAGON SHOWN



UTILITY SHOWN




X118-GP13

B.W.H. GROUND
TAIL LAMP




B.W.H.


V04_12PX118_GP13



R.H.D. SEDAN SHOWN
L.H.D. SIMILAR



A



X322

B

X118-GP16

SUNROOF MODULE
GROUND




B.W.H.


X322

B.W.H. TO S.R.P.H.

S.R.P.H. TO B.W.H.





B.W.H.




S.R.P.H.

V04_12PX118-GP16







"V6" SHOWN



"V6 & V6 S/C"



"V8"




"GEN III V8" ENGINE


X119-GP4 ENGINE GROUND





BATT.W.H.

V04_12PX119_GP04






"GEN III V8" AUTOMATIC SHOWN
"V6 & V6 S/C" SIMILAR



"GEN III V8" MANUAL
SHOWN

X121-X1


SPEED SENDER



P.T.H.


Y144

REVERSE LOCK OUT
SOLENOID




P.T.H.


V04_12PX121_X1




LHD MANUAL A/C SHOWN



A




LHD O.C.C. (AUTO A/C) SHOWN



B

X126-BLO-MOT-LHD FUSE BLOCK



B

A


B.M.H.

*** INFORMATION NOT AVAILABLE
AT TIME OF PUBLICATION**


X204

B.M.H. TO F.B.H.

F.B.H. TO B.M.H.



B




B


B.M.H.

F.B.H.

X126-BLO-MOT-RHD *





V04_12PX126-BLO-MOT





X129

INSTRUMENT PANEL WIRING HARNESS FUSE BLOCK








A

X157


GROUND

X157-GP2

GROUND POST




F.B.H.



VEHICLE BODY





V04_12PX157





X200		X201	
B.W.H TO F.B.H	F.B.H TO B.W.H	B.W.H TO F.B.H	F.B.H TO B.W.H
<p>Diagram showing the pinout for the X200 connector, B.W.H to F.B.H conversion. Pins are numbered: 6, 5, 2, 1, 30, 38, 31, 19.</p>	<p>Diagram showing the pinout for the X200 connector, F.B.H to B.W.H conversion. Pins are numbered: 1, 2, 5, 6, 17, 18, 29, 30, 38, 31, 19, 20, 7, 8.</p>	<p>Diagram showing the pinout for the X201 connector, B.W.H to F.B.H conversion. Pins are numbered: 4, 1, 5, 11, 16, 10.</p>	<p>Diagram showing the pinout for the X201 connector, F.B.H to B.W.H conversion. Pins are numbered: 1, 4, 10, 16, 11, 5.</p>
B.W.H.	F.B.H.	B.W.H	F.B.H.


LEVELS 2 & 3 ONLY

V04_12PX200











SEDAN SHOWN



LEFT SEAT SHOWN



RIGHT SEAT SHOWN


*
X302
X308
X315(A)
X315(B)
(X302 SHOWN)

*
X308
X315(B)
X315(C)
(X308 SHOWN)

* RHD
4 WAY - X302
8 WAY - X308
8 WAY MEM - X315(C)
LHD
4 WAY - X308
6 WAY - X302
8 WAY D - X302
8 WAY P - X308
COUPE
PASSENGER - X308
CV6 DRIVER - X315(A)
CV8 DRIVER (RHD) - X315(B)
CV8 DRIVER (LHD) - X315(A)

X308 * B.W.H TO PS.H


PS.H TO B.W.H



B.W.H.

PS.H.


Y128-R
Y129-L SEAT BELT



B.W.H.

X306-L
X307-R B.W.H TO S.A.B.H.

S.A.B.H TO B.W.H.




B.W.H.

S.A.B.H.

X302 *
X315(A) B.W.H TO PS.H

PS.H TO B.W.H.




B.W.H.

PS.H.

X315(B) * B.W.H TO PS.H

PS.H TO B.W.H.




B.W.H.

PS.H.

X315(C) * B.W.H TO PS.H



PS.H TO B.W.H.



B.W.H.

PS.H.


V04_12PX302




X303

B.W.H. TO F.B.H.

F.B.H. TO B.W.H.




B.W.H.



F.B.H.

V04_12PX303




X310

V.L.H TO R.L.H.


R.L.H TO V.L.H.




V.L.H.




R.L.H.




V04_12PX310





R.H.D
R.H. FRONT DOOR SHOWN
L.H.D. OPPOSITE




A


X600
X500

B.W.H TO R.H.F.D.W.H.
B.W.H TO L.H.F.D.W.H.

R.H.F.D.W.H TO B.W.H.
L.H.F.D.W.H TO B.W.H.



B.W.H.




D.W.H.


X601 R.H.D.
X501 L.H.D.

B.W.H TO R.H.F.D.W.H.
B.W.H TO L.H.F.D.W.H.


R.H.F.D.W.H. TO B.W.H.
L.H.F.D.W.H. TO B.W.H.




B.W.H.



D.W.H. V04_12PX500



SEDAN R. SIDE REAR DOOR
SHOWN, WAGON SIMILAR




X800/ X700

A


X800
X700

B.W.H TO R.H.R.D.W.H
B.W.H TO L.H.R.D.W.H



R.H.R.D.W.H. TO B.W.H.
L.H.R.D.W.H. TO B.W.H.



B.W.H.





D.W.H.



X901


B.W.H. TO E.G.H.

E.G.H. TO B.W.H.



X902

B.W.H. TO E.G.H.





B.W.H.

E.G.H.

B.W.H.


VY12PX901




**X903 R
X904 L**

A

SEDAN R. SIDE
LEVELS 1 & 2 SHOWN
LEVEL 3 & COUPE SIMILAR




**X903 R
X904 L**




B

WAGON R. SIDE SHOWN



**X903 R
X904 L**




C

UTILITY R. SIDE SHOWN


**X903 R
X904 L**

BODY WIRING H. TO
TAIL LAMP H.


TAIL LAMP H. TO
BODY WIRING H.




B.W.H.



T.L.H.




RHD O.C.C. (AUTO A/C) SHOWN




Y19-RHD

A




LHD O.C.C. (AUTO A/C) SHOWN



Y19-LHD

B




Y18

C

Y18

HEATER WATER SHUT-OFF




3

1

O.C.C.H.

Y19-LHD

INSIDE AIR VALVE
VACUUM SOLENOID PACK




1

6

O.C.C.H.

Y19-RHD

INSIDE AIR VALVE
VACUUM SOLENOID PACK




1

3


4

7


O.C.C.H.




SEDAN SHOWN
COUPE SIMILAR




A
WAGON SHOWN
EARLY PRODUCTION







A
WAGON SHOWN
LATE PRODUCTION





A
SEDAN SHOWN
EARLY PRODUCTION




A
SEDAN SHOWN
LATE PRODUCTION


Y23	Y23	Y29	Y29
LIFT GATE LOCK	LIFT GATE LOCK	REAR COMPARTMENT LID LATCH ACTUATOR	REAR COMPARTMENT LID LATCH ACTUATOR
			
E.G.H. EARLY PRODUCTION	E.G.H. LATE PRODUCTION	B.W.H. EARLY PRODUCTION	B.W.H. LATE PRODUCTION








"V6" ENGINE SHOWN
"V6 S/C" SIMILAR




Y123

B



Y123


A



"GEN III V8" ENGINE


Y123




CANISTER PURGE
SOLENOID VALVE



P.T.H.

V04_12PY123






Y143-FCSV

FUEL CONTROL
SOLENOID VALVE

Y143-LOSV

LOCK OFF
SOLENOID VALVE






P.T.H.




P.T.H.

V04_12PY143





B104 NAVIGATION SPEAKER
ASSEMBLY



G.P.S.H.

X207 F.B.H. TO G.P.S.H.


G.P.S.H. TO F.B.H.




F.B.H.

G.P.S.H.


X02




EARLY
PRODUCTION
G.P.S.H.




X01




G.P.S.H.



X02




LATE
PRODUCTION
G.P.S.H.






RIGHT SEAT SHOWN




B

EARLY PRODUCTION




A

LATE PRODUCTION



C

ALL DRIVERS SEATS




H12

D

H12

SEAT BELT ALARM




B



A

PS.H.

V04_12PH012



RIGHT SEAT SHOWN





S267

LATCH SWITCH


R.S.H.

V04_12PS267






LHD SEDAN SHOWN
WAGON & COUPE SIMILAR



A

EARLY PRODUCTION




B

LATE PRODUCTION

Y10


FUEL TANK FILLER
DOOR LOCK



B.W.H. EARLY PRODUCTION

Y10

FUEL TANK FILLER
DOOR LOCK




B.W.H. LATE PRODUCTION


V04_12PY010




RIGHT SEAT SHOWN




A
LEVEL 3 SEAT SHOWN
EARLY PRODUCTION




B
LEVEL 3 SEAT SHOWN
LATE PRODUCTION




D
LEVEL 1 RHD, LEVELS 1 & 2 LHD
& ALL COUPE EXCEPT CV8 DRIVERS



C
LEVEL 2 RHD SHOWN, LEVEL 3
& CV8 DRIVERS SEAT SIMILAR




E
LEVELS 1, 2 &
ALL COUPE EXCEPT CV8 DRIVERS




F
LEVEL 3 & CV8 DRIVERS SEAT

**Y67-D
Y84-P** SEAT INNER ADJUSTER
FRT VERT ACTUATOR




L3, CV8 DRIVERS & RHD L2
P.S.H. EARLY PRODUCTION

**Y67-D
Y84-P** DRIVERS SEAT INNER
ADJUSTER FRT VERT
ACTUATOR




ALL L1, LHD L2, ALL CV6 &
CV8 PASSENGER
P.S.H. EARLY PRODUCTION

**Y67-D
Y84-P** DRIVERS SEAT INNER
ADJUSTER ACTUATOR




P.S.H. LATE PRODUCTION

**Y69-D
Y86-P** DRIVERS SEAT INNER
ADJUSTER REAR VERT
ACTUATOR




L3, CV8 DRIVERS & RHD L2
P.S.H. EARLY PRODUCTION

**Y69-D
Y86-P** DRIVERS SEAT INNER
ADJUSTER REAR VERT
ACTUATOR



ALL L1, LHD L2, ALL CV6 &
CV8 PASSENGER
P.S.H. EARLY PRODUCTION

**Y69-D
Y86-P** DRIVERS SEAT INNER
ADJUSTER ACTUATOR



P.S.H. LATE PRODUCTION