

Cruise Control System Diagnostic Chart

(CRUISE SYSTEM TROUBLESHOOTING WITH A HIGH IMPEDANCE DIGITAL VOLTMETER)

(refer to Section 12H, FUSES, WIRING HARNESS AND WIRING DIAGRAMS in this Manual for details of connector body and wiring identification)

TROUBLESHOOTING HINTS

1. Cruise fuse 10, O.K. if power windows and door locks (if fitted) are working.
2. "Speedo" fuse is O.K. if speedometer or odometer is operating.
3. Check connector or YB68 at right side switch block assembly and Cruise Control Module connector YE56 for proper connection.
4. Check that cruise module linkage is connected and moving freely.
5. Check cruise cable adjustment, refer 2.1 in this Section.
6. For identification of connector YE56 connector terminals, refer Fig. 12E-34. For cruise control switch terminal identification, refer Fig. 12E-32.

