

Circuits

Engine C12NZ	1400 - 1449
Engine C14NZ	1400 - 1449

Grounding points

3	Engine, right
4	Engine, right

Abbreviations

AC	Air conditioning
AT	Automatic transmission
DIAG	Diagnostic link
IMO	Immobiliser
INS	Instrument
KSP	Fuel pump
LHD	Left-hand drive
RHD	Right-hand drive

Component codes

K20	Ignition module - Ignition coil
K57	Control unit - Multec
K58	Relay - Fuel pump
L1	Ignition coil
M66	Actuator - Idle speed

P23	Sensor - Absolute pressure, intake manifold
P30	Sensor - Coolant temperature
P33	Sensor - Oxygen, exhaust
P34	Potentiometer - Throttle valve
X4	Instrument panel & Engine
X5	Instrument panel & Engine
X15	Code octan rating
X43	Instrument panel & Engine
X73	Engine & Control unit - Multec
X74	Engine & Control unit - Multec
X87	Instrument panel & Engine
Y10	Ignition distributor - Hall sensor
Y32	Injection valve - Fuel

